

Cooker hob S4000 Induction 7332 240

Cooker hobs Code: 7332 240




DETAILS


| Coloring | Black |
|------------------------|---|
| Material | Ceramic glass |
| Edge/Installation Type | Bevelled Edge - for flush-mount or over-mount installation |
| Dimensions | 800x520 mm |
| Base size | 80cm |
| Heating element | Four zones |
| Built-in hole | View technical data sheet (for all Flush-mount / Top-mount models and Under-mount models) |
| Total power | 7.400 W |
| Left | Ø 250 mm-2.300 (3.000)* W |

| Centre | Ø 180 mm-1.200 (1.400)* W |
|----------------------------|---|
| Right | Ø 220 mm-2.300 (3.000)* W |
| Up-right | Ø 160 mm-1.200 (1.400)* W |
| Power settings | 9 power settings per zone + Powerboost |
| Safety | Safety equipment |
| Туре | Induction Hob |
| Type of commands | Touch Control |
| Notes: | * Powerboost |
| FEATURES | |
| Powerboost | Booster function provides increased power to the selected plate. In particular, when the Booster is activated, the plate works for ten minutes at a very high power that allows to heat quickly large quantities of water. |
| Pot detector | All induction cooker hobs detect the pot resting on them, but they also calculate the area they cover. This system allows the energy to be used even more efficiently. Moreover, the plates switch off automatically when the pot is removed. |
| End-of-cooking programming | All operations are programmed by means of the touch-control on the glass itself. Each cooking plate is capable of independent programming, and thus the possibility to set different cooking times. |
| Timer | Indipendent timer from the end-of-cooking function. |

| Slider commands | The Slider control allows for extremely quick temperature setting: with a light touch of the finger you may select the desired power level on the TOUCH display. |
|------------------|--|
| Heat maintenance | Function that allows the food to be kept warm gently (70° C), without reaching boiling temperatures or risking to burn the sauce. |
| Go&stop function | This device initially turns on the plates at maximum power until the selected temperature has been reached. |
| Recall | This feature allows you to call back the last settings selected in the previous cooking. |
| Smart fan system | Correct ventilation is essential for the induction hob to function in the best possible way. The Foster system automatically regulates the amount of ventilation to suit the temperatures reached. |
| Pause | Useful function that allows you to distract your attention from cooking, interrupting and restoring the settings immediately. |
| Safety | All electric cooker hobs feature the most modern and sophisticated safety protections: Centralised power-off function; Child-proof safety lock; Residual heat warning lights. Induction models feature the following functions: Safety System that turn off the hob in the absence of the pot; Overflow detector that automatically turns off the plate in case of liquid overflow; Automatic deactivation to prevent accidents caused by forgetfulness. |

TECHNICAL DATA





OPTIONAL ACCESSORIES



Induction Pro - Cookware set -8pcs 8210 008

RECOMMENDED PAIRINGS



Hood S4001 island 2442 __1



Sink Milanello workstation 1040 05x