


## CASTONE LINEAR

Induction Hobs

Code: 7439 000



### DETAILS

|                  |                                               |
|------------------|-----------------------------------------------|
| Kind of Edge     | Full - h 4mm                                  |
| Material         | AISI 304 stainless steel                      |
| Material         | Ceramic glass                                 |
| Thickness        | 4 mm                                          |
| Supply           | 230 - 380 V (50/60 Hz)                        |
| Dimensions       | 1080x490 mm                                   |
| Full description | Quadra Modular Composition - 3 fields - black |
| Heating element  | Three zones                                   |
| Width            | 108 cm                                        |


|                  |                                        |
|------------------|----------------------------------------|
| Total power      | 6.700 W                                |
| Left             | 2.300 (3.000)* W                       |
| Centre           | 1.100 (1.400)* W                       |
| Right            | 2.300 (3.000)* W                       |
| Power settings   | 9 power settings per zone + Powerboost |
| Safety           | Safety equipment                       |
| Type             | Induction Hob                          |
| Type of commands | Touch Control                          |
| Notes:           | * Powerboost                           |

## FEATURES

|                  |                                                                                                                                                                                                                                               |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Powerboost       | Booster function provides increased power to the selected plate. In particular, when the Booster is activated, the plate works for ten minutes at a very high power that allows to heat quickly large quantities of water.                    |
| Pot detector     | All induction cooker hobs detect the pot resting on them, but they also calculate the area they cover. This system allows the energy to be used even more efficiently. Moreover, the plates switch off automatically when the pot is removed. |
| Smart fan system | Correct ventilation is essential for the induction hob to function in the best possible way. The Foster system automatically regulates the amount of ventilation to suit the temperatures reached.                                            |

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| End-of-cooking programming | All operations are programmed by means of the touch-control on the glass itself. Each cooking plate is capable of independent programming, and thus the possibility to set different cooking times.                                                                                                                                                                                                                                                      |
| Slider commands            | The Slider control allows for extremely quick temperature setting: with a light touch of the finger you may select the desired power level on the TOUCH display.                                                                                                                                                                                                                                                                                         |
| Timer                      | Independent timer from the end-of-cooking function.                                                                                                                                                                                                                                                                                                                                                                                                      |
| Heat maintenance           | Function that allows the food to be kept warm gently (70° C), without reaching boiling temperatures or risking to burn the sauce.                                                                                                                                                                                                                                                                                                                        |
| Go&stop function           | This device initially turns on the plates at maximum power until the selected temperature has been reached.                                                                                                                                                                                                                                                                                                                                              |
| Recall                     | This feature allows you to call back the last settings selected in the previous cooking.                                                                                                                                                                                                                                                                                                                                                                 |
| Pause                      | Useful function that allows you to distract your attention from cooking, interrupting and restoring the settings immediately.                                                                                                                                                                                                                                                                                                                            |
| Safety                     | All electric cooker hobs feature the most modern and sophisticated safety protections: Centralised power-off function; Child-proof safety lock; Residual heat warning lights. Induction models feature the following functions: Safety System that turn off the hob in the absence of the pot; Overflow detector that automatically turns off the plate in case of liquid overflow; Automatic deactivation to prevent accidents caused by forgetfulness. |

## TECHNICAL DATA






FTS - cut out

FT - cut out

---



## GALLERY



## OPTIONAL ACCESSORIES



**Induction Pro - Cookware set - 8pcs**  
8210 008



**Induction PRO - Grill pan**  
8212 000



**Induction Pro - Wok pan with flat bottom PRO**  
8211 000